



- Tubular motor brand 'Nice'
- Motor on the right side
- Projection screen fabric falls from the back



Bottom view

If you want to adjust the up position:



- Turn clockwise to let the screen stop at a lower position
- Turn counter-clockwise to let the screen stop at a higher position

If you want to adjust the down position:

- Turn clockwise to let the screen stop at a higher position
- Turn counter-clockwise to let the screen stop at a lower position

!! you will only see the adjustment when controlling the screen !!

- Tubular motor brand 'Nice'
- Motor on the left side
- Projection screen fabric falls from the back



Bottom view

If you want to adjust the up position:


- Turn clockwise to let the screen stop at a lower position
- Turn counter-clockwise to let the screen stop at a higher position

If you want to adjust the down position:

- Turn clockwise to let the screen stop at a higher position
- Turn counter-clockwise to let the screen stop at a lower position

!! you will only see the adjustment when controlling the screen !!

- Tubular motor brand 'Nice'
- Motor on the right side
- Projection screen fabric falls from the front



Bottom view

If you want to adjust the down position:



- Turn clockwise to let the screen stop at a lower position
- Turn counter-clockwise to let the screen stop at a higher position

If you want to adjust the up position:

- Turn clockwise to let the screen stop at a higher position
- Turn counter-clockwise to let the screen stop at a lower position

!! you will only see the adjustment when controlling the screen !!

- Tubular motor brand 'Nice'
- Motor on the left side
- Projection screen fabric falls from the front



Bottom view

If you want to adjust the down position:

- Turn clockwise to let the screen stop at a lower position
- Turn counter-clockwise to let the screen stop at a higher position

If you want to adjust the up position:

- Turn clockwise to let the screen stop at a higher position
- Turn counter-clockwise to let the screen stop at a lower position

!! you will only see the adjustment when controlling the screen !!