1 Protective and area to work





Essential Tools



Tip



Provided




2
1
x 4
Do NOT forget this step
2
x 4
x 4
3
screen < 120"
1
x 4
4
x 6
Do NOT forget this step
5
x 4
6
4
x 6


2
1
x 4
Do NOT forget this step
2
3
Do NOT forget this step
x 4
4
3 holes
3 holes
3 holes
3 holes
5
2 holes
3 holes
x 2

3

These brackets must be used if stiffeners ARE provided !







Recommended Positioning.
Position of wall-mounts is adjustable on frame.





4 Installation of frame stiffeners.





5



6 IMPORTANT: Read these instructions BEFORE tensioning fabric

1 - Recommended method.





1 Use your **body weight** to insert the Pi-Grip in one short and powerful move, firmly but smoothly, in the center of the length.

2 Use the same technique, working out from the center of the Pi-Grip towards each end.

2 - The Method.





3 - Pi-Grip insertion sequence.



CAUTION: Do not manually over-tension the fabric. Fitting the Pi-Grip will apply the correct tension



If the fabric is not flat, the tension is not correct. If this is the case, remove the Pi-Grip and re-fit applying more manual tension.

7 TIP: Use the groove of the aluminium profile as a guide to cut the excess fabric.



Place the fabric inside the frame



8 Black backing installation follows the same principle as fabric fitting.



Lay the Black Backing on your screen.
Slip it under brackets.

VERY IMPORTANT
Do not tense Black backing !
Over-tensing it can damage the screen.

Loose Black backing will not have any effect on video or audio results and minimize the constraint on the frame.



9 Black Backing layer: Pi-Grip insertion sequence and positioning.



Space the short Pi-Grip pieces around the frame evenly (approximately every 25cm/10") starting at the center of each side of the frame.
Continue in the same fitting sequence as for the screen fabric.



CAUTION: Do not manually tense the fabric





10 Hang the screen according to the chosen kind of brackets.